

Press Release

High Bond Kit

Re-assembly of rearview mirrors made easy

Duisburg, November 2017. Safely re-attaching rearview mirrors after the original adhesive has given up or the windscreen was replaced - what sounds like a trivial task at first is not as easy as it seems. After all, general road safe-ty of the vehicle is directly concerned. With the new product "High Bond Kit" for the automotive segment, KENT now offers a new solution best suited for professional application with highest demands to quality.

High Bond Kit was especially designed for small structural assemblies of glass to metal, which makes it best suited for re-installing rearview mirror brackets on vehicle windscreens which have fallen off - or when the mirror needs to be rein-stalled after the windscreen was replaced. The repair is invisible and the fastest on the market. Secure adhesion is guaranteed by the two-component structural adhesive.

After only five minutes the adhesive has achieved handling strength. Clamping is not required - High Bond Kit bonds reliably in just 30 seconds. Furthermore, High Bond Kit has a high resistance to impacts and vibrations. Application is easy and intelligent and thus typical for KENT: The primer comes in a bottle with a brush. The product can hardly be applied wastefully, overspraying does not occur as well. But this is not the only reason the product speaks to cost-aware users: One package contains enough to last for 50 to 75 applications.



And this is how easy application of High Bond Kit comes: Mark the location of the mirror bracket on the outside of the windscreen for reference. Thoroughly clean the glass mounting surface and the mirror bracket. Use a razor blade to remove stubborn adhesive residues and degrease with KENT's Soft Surface Cleaner. Brush the primer on the glass where the bracket will be installed and then brush the primer on the mirror bracket. Let the primer dry for 30 seconds. Apply two drops of the adhesive to the bracket. When you are ready to install the rearview mirror bracket, be careful to place it exactly on the previously marked location. Hold the bracket steady for 30 seconds.

Wait 5 minutes before removing any excess adhesive with a razor blade and in-stall the rearview mirror on the bracket.

High Bond Kit is applicable for all types of rearview mirrors, also when it comes to tractors or trucks. The shelf life is 12 months as from opening it for the first time. Fast results, long shelf life, quick to reach handling-strength - High Bond Kit does not need to shy from comparison and at this time is one of the most professional products for re-assembly of rearview mirrors.

Available:

High Bond Kit 15 ml primer + 15 ml adhesive